

# Appendix - Full Post Install

1. For each screw used in the post, pre-drill through the center of the 2 walls of the post, a 5/16" hole. If using a 3'- 4' post, drill 3 holes. If using a post over 4' in length, drill 4 holes. 1st and last holes are drilled 4" from each end, and the remainder equally spaced.
2. Drill a 1" hole in the outside face of the post.
3. Place the post at the required position on the wall and with a marker, mark the hole center of all holes, on the wall.
4. Drill 3/16" holes on the marks.
5. Attach the post to the wall using concrete anchor screws.
6. Fit the hole plugs to the 1" holes.

